

SCUPPER PUP ASSEMBLY INSTRUCTIONS



The Scupper Pup is supplied with the 11" – 18" crossbar in place. You may find your boat scupper holes need the shorter crossbar set which is included (6" – 11").

To change crossbars, transfer snap button from long crossbar to shorter one. Manually turn thumb screws holding crossbar to T-fitting.

Do not loosen screws securing T-fitting to upright bars. Slide out long tubes from T-fitting and replace with shorter tubes with snap button inserted. Align thumb screws with holes in crossbars. Tighten thumb screws by hand firmly.

Continue assembly as in first step.

USING THE SCUPPER PUP

With boat lying flat, choose scupper (drainage) holes you want to use. Adjust Scupper Pup's upright bars so they pass through those drainage holes.

Stand next to boat slightly behind the scupper holes you will use. Roll boat over and balance it on its side, propping it up with your leg if necessary.

Slide Scupper Pup's upright bars through scupper drainage holes.

Roll boat back onto Scupper Pup wheels. You are now ready to pull or push your boat to the water. Upright bars may tilt toward you when you pull or tilt away from you when you push the boat. This is normal.

CAUTION

- Never tow Paddleboy® with any vehicle.
- Do not carry passengers in the craft while portaging.
- Damage to the craft or boat cart, or injury may result from improper use.

WARNING

Portaging a canoe, kayak or other craft is a strenuous activity. Prior to engaging in any strenuous activity (including that involving Paddleboy®), the user should consult a medical professional to determine whether physical strain is appropriate.

By purchasing this Paddleboy® product the purchaser agrees for himself/herself and for any and all other users to release and waive all claims against Paddleboy® for damages or injury which may result from the use of this product.

WARRANTY

Seattle Sports will repair or replace (at its discretion) any broken or defective parts for one year from date of purchase. The customer will be responsible for the cost of shipping the Paddleboy® back to the factory. Seattle Sports will pay all return shipping costs to customer.

The customer takes responsibility for the proper attachment and use of the Paddleboy®. Seattle Sports cannot be responsible for any damage to any property arising out of the use or misuse of its product. Call first for return authorization: 800 632 6163. Return to Seattle Sports Co. 1300 N. Mariposa Ranch Rd., Nogales, AZ. 85621

Slide crossbar tubes together, leaving foam padding on bars. To hold tubes in position, allow snap button to emerge from one of the holes in crossbar. Some holes may be hidden beneath foam padding.

If possible, judge which hole to use by the distance between drainage or scupper holes in your kayak. Holes on crossbar and holes in kayak may not align. Then, slide crossbars to match holes in kayak without use of snap button. Snap button is not necessary to have cart function properly. Slip the foam pad over the joint of the tubes. A little Armor All® on tubes may help (do not use oil).

QUICK RELEASE WHEELS



locate push-button



press down to clear wheel hub



push axle through



When attaching to axle, rotate wheel slowly until tab settles and wheel sits snug (the push-button should be popped out)