

SCUPPER PLUGS

INSTRUCTIONS



USING YOUR SCUPPER PLUGS

STEP 1

Remove Scupper Plugs from packaging.

STEP 2





Insert Scupper Plugs into the scupper holes on your boat in the areas that you want to keep dry. Insert the Scupper Plug as deeply as possible into the hole, to achieve the best seal.

STEP 3

If Scupper Plug is not inserted deeply enough it may allow water into the boat. If this happens, just push plug deeper into the scupper hole for a better seal.

**High resolution green silicone.*

**Ergonomic design for easy installation and removal.*



WARNING

Due to the fact that Seattle Sports does not have control over how this device is used, Seattle Sports disclaims any and all liability for damage or injury that might occur as a result of the improper use of this product.

WARRANTY

Seattle Sports products are guaranteed for materials and workmanship for one year. Normal wear and tear or damage from misuse, accident, or alterations are not covered. Use of this product in a professional setting is not covered. Seattle Sports assume no liability for incidental damages or injuries resulting from the use or misuse of this product. You may have additional warranties or limitations outlined in product packaging. Thank you for purchasing our products. Please contact us with any questions or concerns about our products. Seattle Sports Company, 3217 W. Smith St #1, Seattle WA 98199. seattle.sports.co.com

Copyright 2012