

How to assemble Beach Wheel Kit



- BEACH AXLE C-CLIP MOUNTING BRACKETS (TWO) Part A
- BEACH WHEEL BOLT Part B
- BEACH AXLE COTTER PINS (TWO) Part C
- BEACH WHEEL Part D
- BEACH WHEEL AXLE Part E
- BEACH AXLE QUICK-RELEASE PIN Part F
- KAYAK CART (not included - for reference only) Diagram G

1. Attach one Beach Axle C-Clip (part A) to Beach Wheel Axle (part E) by nesting Beach Wheel Axle into C-Clip and aligning holes
2. Sliding stainless Steel Bolt (part B) through holes, tighten on washer and nut
3. Slide R-shaped Cotter Pin (part C) into one of two holes in center of Beach Wheel Axle (part E)
4. Slide Beach Wheel (part D) on to Beach Wheel Axle (part E) so it butts up against Beach Axle Cotter Pin (part C) installed in step #3
5. Slide second Beach Axle Cotter Pin (part C) into Beach Wheel Axle (part E), so Beach Wheel (part D) is locked in place on Beach Wheel Axle, between two Beach Wheel Cotter Pins

NOTE: You now have a fully assembled Beach Wheel Kit (part X) to be used in Step 8

6. Remove Cart Axle Pin (kayak cart diagram G) from the end of the Kayak Cart Axle and remove Kayak Cart Wheel and repeat for opposite Kayak Cart Wheel
7. Slide second Beach Axle C-Clip (part A) onto Kayak Cart Axle and replace Kayak Cart Wheel making sure C-Clip is facing same direction as C-Clip already mounted to Beach Wheel Axle in step #1
8. Slide Beach Axle C-Clip (part A) on to opposite Kayak Cart Axle, so the axle of the fully assembled Beach Wheel Kit (part X) is attached to cart on one end
9. Fit Beach Wheel Axle into C-Clip installed in Step 7, and align holes
10. Slide Beach Axle Quick-release Pin (part F) through C-Clip and Beach Axle holes, and lock by pulling C-shaped opening over pin
11. Re-install Kayak Cart Wheels