

# FROST PAK

## SOFT COOLER CARE AND USE



### INSTRUCTIONS

**STEP 1**  
Prep your food! Use Tupperware™ to prevent bruising soft, perishable items.

**STEP 2**  
Ice right! Use ice packs or frozen water bottles to prevent water damage to your food. Use crushed ice or block ice for cooling canned or bottled beverages.

*\*WARNING: DO NOT USE DRY ICE IN THESE COOLERS\**

**STEP 3**  
Shut it down! Keep your Frost-Pak closed to avoid cooling loss.

### STEP 1




### STEP 2

*\*WARNING: DO NOT USE DRY ICE IN THESE COOLERS\**



### STEP 3



### CARE

*To clean after each use, rinse with mild soapy water, squeeze out any excess water and hang upside down to dry*

### WARNING

Frost-Pak Soft Coolers are not waterproof. Zippers and stitched seams can leak. Returns will not be accepted for claims stating this product waterproof.

### WARRANTY

Seattle Sports products are guaranteed for materials and workmanship for one year. Normal wear and tear or damage from misuse, accident, or alterations are not covered. Use of this product in a professional setting is not covered. Seattle Sports assume no liability for incidental damages or injuries resulting from the use or misuse of this product. You may have additional warranties or limitations outlined in product packaging. Thank you for purchasing our products. Please contact us with any questions or concerns about our products. Seattle Sports Company, 3217 W. Smith St #1, Seattle WA 98199. [seattlesportsco.com](http://seattlesportsco.com) Copyright 2016